

DAIHATSU

Rocky


CHARGING SYSTEM

CH


1. COMPONENTS	CH- 2
2. CHARGING SYSTEM CIRCUIT	CH- 3
3. TROUBLE SHOOTING	CH- 3
4. DESCRIPTION	CH- 4
5. IN-VEHICLE INSPECTION	CH- 7
6. REMOVAL	CH-11
7. DISASSEMBLY	CH-12
8. INSPECTION	CH-14
9. ASSEMBLY	CH-20
10. INSTALLATION	CH-23

WRU90-CH001

1. COMPONENTS



2. CHARGING SYSTEM CIRCUIT



WRU90-CH003

3. TROUBLE SHOOTING

Problem	Possible causes	Remedies
Charge warning lamp will not glow even if ignition switch is turned ON.	Fuse blown Lamp bulb burnt Poor connection of wiring Open wire IC regulator faulty	Check gauge fuse. Replace bulb. Repair poor connection of wiring. Repair or replace. Replace regulator assembly.
Charge warning lamp will not go out even if engine has started.	Drive belt loose or worn Battery cables loose, corroded or worn Fuse blown Fusible link blown IC regulator or alternator faulty Wiring faulty	Adjust or replace. Repair or replace cables. Check gauge fuse. Replace fusible link. Check charging system. Repair or replace.

WRU90-CH004

4. DESCRIPTION

The charging device consists of an alternator and a regulator. The alternator produces alternating current (AC), which is converted to direct current (DC) by a rectifier.

The battery supplies power for operating the starter as well as power required while the engine is stopped.

The alternator recharges the battery so as to maintain it in an operational state at all times. The alternator also furnishes power for the electric equipment.

Electricity is produced when a magnet is moved in the vicinity of a coil. When the magnet is getting close to the coil, voltage is produced in one direction. However, when the magnet is leaving the coil, the direction of the voltage changes. This type of current is generally called alternating current, for the direction of the current is alternating.


The main purpose of a generator for motor vehicles is to charge the battery. Hence, a generator which produces alternating current is not suited for this purpose. It is, therefore, necessary to convert alternating current to direct current. As semiconductor technology has advanced, today it has become possible to convert alternating current to direct current at a low cost. Consequently, alternators (AC generators) have been commonly used. The following are advantages of alternators compared with DC generators.

- (1) Compact design, light weight and remarkable vibration-resistant characteristics
- (2) Capable of withstanding high-speed rotation, quick acceleration and deceleration.
- (3) Being endurable under severe environment prevailing with dirt, dust and moisture, etc.
- (4) Having a fewer number of consuming parts and being easy to repair


The alternator has three pairs of stator coils and rotor (coil) and produces three-phase current. The alternator employs six rectifiers, which performs three-phase full-wave rectification. The generated voltage (electromotive force) is in proportion to the strength of the magnetic field (magnet). This means that the voltage is proportional to the current of the rotor coil and to the rotation speed, i.e. the moving speed of the magnet.

The generated voltage varies as the engine revolution speed of the vehicle changes. It is, therefore, necessary to regulate the voltage so that the battery can be charged. For this purpose, the current of the rotor coil is regulated, thereby producing a regulated generator voltage. To achieve this operation, a regulator has been employed.

The regulator is of an IC (integrated circuit) type and it is built inside the alternator itself.



WRU90-CH005



WRU90-CH006

The electromotive force generated in a coil is generally expressed by the following formula.

$$e = -N \cdot \frac{d\phi}{dt}$$

where,

e : Induced electromotive force in coil (V)

N : Number of turns of wire in coil

$\frac{d\phi}{dt}$: Rate of change in magnetic flux (ϕ) per unit time

– : This means voltage is generated in such a direction that the change in magnetic flux is prevented.

The magnetic flux increases in proportion to the current of the rotor coil. However, as the magnetic flux is reaching a saturation point, the increase of the magnetic flux is no longer proportional to the current.

The output of the alternator increases as the rotation ($\frac{d\phi}{dt}$) increases, eventually reaching a saturation point.

This saturation is believed to be caused by the decline of the rate of change ($\frac{d\phi}{dt}$) i.e. the rate of change in magnetic flux (ϕ) per unit time when the magnetic flux of the rotor is applied to the stator coil.


Besides the controlling by the magnetic flux and rotation speed described above, the output is restricted by the electric resistance of the stator coil. This resistance, mainly attributable to the induction reactance of ac current, increases as the frequency (rotation speed) rises.

The alternator is so designed that its electromotive force is generated at the stator coil. Therefore, the alternator features easy cooling and virtually trouble-free operation.




To connect the three pairs of stator coils, a "Y" connecting method is employed. Although this Y connecting method is inferior to a Delta-type connecting method in the maximum output current, the Y connecting method has a greater electromotive force at lower speeds. Moreover, the Y connecting method has an advantage of use of the neutral point. For these reasons, the Y connecting method has been widely used on small capacities less than 1 kW.

The stator assembly is made up of a laminated iron frame. This construction has been adopted so as to hold the stator coil and allow the magnetic flux from the rotor to pass through the coil easily (improvement of permeability).

The installation of an iron core in the coil increases the self inductance. This causes an increase of the inductive reactance in the case of AC current, resulting in reduced electromotive force. However, in the case of comparatively-low frequencies, the installation of iron core has more favorable effects in increasing the electromotive force which is attained by improved permeability, even counteracting the aforesaid disadvantage. For this reason, the iron core is generally employed. The purpose of slots provided at the core is to retain the wound stator coil. These slots also serve as magnetic flux passages which have been so designed that the rotor magnetic flux intersects the stator coil effectively.






WRU90-CH007



WRU90-CH008

CHARGING SYSTEM

Theoretically speaking, six pieces of diodes are sufficient for full-wave rectification. However, the latest alternators have employed two more diodes for the purpose of utilizing the electromotive force at the neutral point. As a result, the latest alternator can produce a greater output current than the conventional alternators.



WRU90-CH009

5. IN-VEHICLE INSPECTION


CAUTION:

- Never touch at the battery terminals immediately after the vehicle has been operated.
- Be certain to turn OFF the ignition key switch during the inspection.

WRU90-CH010

- (1) Check the battery case for proper installing condition and cracks.

If the batter case exhibits improper installing condition or cracks, replace or repair the battery, as required.




WRU90-CH011

- (2) Check to see if the battery terminals exhibit corrosion and/or loose condition.

If the battery terminals exhibit corrosion and/or loose condition, remove the battery cable terminals from the terminal of the battery. Remove any rust, using a wire brush or a fine abrasive paper. After the battery terminals have been connected, coat these terminal with a thin film of lithium grease.

NOTE:

- After the battery terminals have been cleaned, make sure that no rust particle remains on the terminals.



WRU90-CH012

- (3) Check battery specific gravity and electrolyte level
Check the color of the Hydrometer.

REFERENCE (For Delco battery):


Green dot is visible:

The battery is adequately charged.

Dark (The green dot is invisible.):

The battery must be charged.

Clear or light yellow: Replace the battery.



WRU90-CH013


NOTE:

- On the Delco battery, it is impossible to add the electrolyte, for it is permanently sealed.

- (4) Check of battery terminals

① Visually check the battery terminals for corrosion.

If necessary, clean and flush the terminals, using a brush with baking soda solution.




WRU90-CH014

CHARGING SYSTEM

- ② If the inside of the clamp at the cable side becomes corroded, clean out the terminal with a wire brush or coarse emery cloth.

NOTE:


- Coat the terminal sections of the battery with a thin film of grease. This is an effective method to prevent rust formation.



WRU90-CH067

(5) Inspection of drive belt

- ① Visually check the belt for separation of the adhesive rubber above and below the core, core separation from the adhesive rubber, cracking or separation of the ribs, torn or worn ribs or cracks in the inner ridges of the ribs. If necessary replace the drive belt.



WRU90-CH068

② Measurement amount of belt deflection

Push the midpoint of the drive belt between the alternator pulley and the water pump pulley by applying a force of 22 lb (10 kg). Measure the deflection of the drive belt.

Specified Belt Deflection


New belt: 4.0 - 5.0 mm (0.16 - 0.19 inch)

(With a pressed force of 22 lb (10 kg) applied to a point indicated in figure)

Used belt: 5.0 - 6.0 mm (0.20 - 0.23 inch)

(With a pressed force of 22 lb (10 kg) applied to a point indicated in figure)

Adjust the drive belt tension, if necessary.



WRU90-CH069

NOTE:

- "New belt" refers to a belt which has been used less than 5 minutes on a running engine.
- "Used belt" refers to a belt which has been used on a running engine for 5 minutes or more.
- After replacing the drive belt, check that it fits properly in the ribbed grooves, especially in the places difficult to see.
- After installing a new belt, run the engine for about 5 minutes and then recheck the tension.


WRU90-CH070

- (6) Check of fuses for continuity
 - Fusible link
 - Fusible link block
 - EFI No. 1 fuse
 - Engine fuse
 - Gauge fuse
- (7) Checking alternator wiring and listening for abnormal noises
 - ① Check to see if the alternator wire is connected properly to the alternator.
 - ② Ensure that the alternator emits no abnormal noise while the engine is running.

WRU90-CH071

- (8) Check of charge warning lamp circuit
 - ① Turn OFF all accessory switches.
 - ② Start the engine and warm up the engine thoroughly. Turn OFF the ignition switch.
 - ③ When the ignition switch is turned ON, ensure that the charge warning lamp goes on.
 - ④ After the engine has started, ensure that the charge warning lamp goes out.

If the warning lamp does not function as specified, troubleshoot warning lamp circuit.




WRU90-CH072

- (9) Check of charging circuit under no-loaded state

NOTE:

- If a battery/alternator tester is available, connect such tester to the charging circuit according to the manufacturer's instructions.

- ① If such a tester is not available, connect a voltmeter and an ammeter to the alternator wiring and alternator as follows:
 - Disconnect the battery ground cable from the negative (-) terminal of the battery.
 - Connect an ammeter in series between the alternator wire terminal B and the alternator as indicated in the right figure.
 - Connect the positive (-) terminal of a voltmeter to the terminal B as indicated in the right figure.
 - Connect the negative (-) terminal of the voltmeter to the engine ground.
 - Wind vinyl tape around each connection section so as to prevent short.
 - Reconnect the battery ground cable to the negative (-) terminal of the battery.



WRU90-CH073

CHARGING SYSTEM

- ② Check the charging circuit as follows:
- (1) Start the engine and warm it up.
 - (2) Raise the engine speed from the idle speed to 2000 rpm. Take the readings of the ammeter and voltmeter.

Standard Amperage: Not to exceed 10 A

Standard Voltage: 13.5 - 14.3 V


If the voltage reading is greater than the standard voltage, replace IC regulator.

If the voltage reading is less than the standard voltage, ground the terminal F as indicated in the right figure.


Proceed to start the engine.

If the voltage reading becomes greater than the standard voltage under this setting, replace the IC regulator.

If the voltage reading is still less than the standard voltage under this setting, check the alternator.



WRU90-CH074



WRU90-CH075

(10) Check of charging circuit under loaded state

- ① Start the engine. Maintain the engine speed at 2000 rpm.


Turn ON the high beams of the headlamps and set the blower fan motor switch to the Hi position. Take the reading of the ammeter.

Standard Amperage: 30 A or more

If the ammeter reading is less than 30 A, repair the alternator. (See page CH-8.)

NOTE:


- When the battery is in a fully charged state, the ammeter reading may be less than 30 A during the aforesaid test.



WRU90-CH076


6. REMOVAL

- (1) Disconnect the ground cable terminal from the negative (-) terminal of the battery.




WRU90-CH015

- (2) Disconnection of wires from alternator
① Remove the nut and wire from the alternator.



WRU90-CH016

- ② Disconnect the connector from the alternator.



WRU90-CH017

- (3) Removal of alternator drive belt
Loosen the alternator attaching bolts. Remove the drive belt.

- (4) Removal of alternator
① Remove the alternator attaching bolts.
② Remove the alternator from the engine compartment.


WRU90-CH018

7. DISASSEMBLY

- (1) Remove the alternator pulley lock nut by means of an impact wrench.

NOTE:


Be sure to use an impact wrench having a hexagonal hole.



WRU90-CH019


- (2) Removal of rear end cover

- ① Remove the nut and terminal insulator.
- ② Remove the three screws.
- ③ Remove the rear end cover.




WRU90-CH020

- (3) Remove the brush holder.



WRU90-CH021


(4) Remove the regulator assembly.



WRU90-CH022

(5) Removal of rectifier holder


① Remove the attaching screws.



WRU90-CH023

② Straighten the stator wire.

③ Remove the rectifier holder.




WRU90-CH024

(6) Remove the rectifier end frame from the drive end frame by removing the two nuts and bolts.


NOTE:

- Be very careful not to damage the stator wire
- If any difficulty is encountered in the removal, lightly tap the shaft with a plastic hammer to facilitate the removal.



WRU90-CH025

(7) Remove the rotor from the drive end frame assembly.




WRU90-CH026

8. INSPECTION

(1) Rotor


- ① Inspection of rotor for open circuit
Using an ohmmeter, check to see if specified resistance exists between the rotor slip rings.
Standard Resistance: $2.9 \pm 0.2 \Omega$

If no specified resistance exists, replace the rotor.




WRU90-CH027

- ② Inspection of rotor for ground
Ensure that no continuity exists between the rotor slip rings and the rotor core.
If continuity exists, replace the rotor.



WRU90-CH028

- ③ Inspection of slip rings
 - a. Check to see if the slip ring surface exhibits roughness, abnormal wear and/or burning.
Replace the rotor, if necessary.




WRU90-CH029

- b. Measure the outer diameter of the slip ring, using vernier calipers.

Standard Diameter: 14.4 mm (0.57 inch)

Minimum Diameter: 14 mm (0.55 inch)


If the slip ring diameter is less than the minimum diameter, replace the rotor assembly.



WRU90-CH030


(2) Stator

- ① Inspection of stator for open circuit
Using an ohmmeter, check to see if any open circuit of the stator coil is present between the leads.
If no continuity exists, replace the end frame assembly.
Specified Resistance: About 0.2 Ω



WRU90-CH031

- ② Inspection of stator for short circuit
Using an ohmmeter, check to see if any short circuit of the stator coil is present between the coil lead and the drive end frame.
If continuity exists, replace the drive end frame assembly.




WRU90-CH032

(3) Brush and Brush Holder

- ① Measurement of exposed brush length
Measure the exposed brush length, using a scale.
Standard Exposed Length: 10.5 mm
Minimum Exposed Length: 1.5 mm

If the exposed length is less than the minimum requirement, replace the brushes.




WRU90-CH033

- ② Replacement of brushes (If necessary)
 - a. Remove the brush and spring from the brush holder by melting the solder by means of a soldering iron.

NOTE:

- Prior to the operation, remove the painting film at the solder surface with a knife or the like.
- For this operation, it is advisable to use a soldering iron with a capacity of about 40 W.




WRU90-CH034

- b. Install the brush cord in the brush holder with the spring fitted in place.

NOTE:

- Using a knife, etc., remove the soldered section of the brush holder to form a flat surface until the bare metal is exposed.



WRU90-CH035


CHARGING SYSTEM

- c. Solder the brush cord in the brush holder in such a way that the exposed length of the brush meets the specification.

Standard Exposed Length: 10.5 mm


NOTE:

- Prior to the operation, let solder flow onto the forward end of the brush wire.
- To facilitate soldering:
Route the wire through the holder hole and adjust the exposed length of the brush to the specification. Bend the wire at its forward end on which solder has been applied in the preceding step. Then, solder the wire to the holder.




WRU90-CH036

- d. Ensure that the brush moves freely in the brush holder.



WRU90-CH037


- e. Cut off any excess remaining wire and apply an insulation paint.



WRU90-CH038


(4) Rectifier

- ① Inspection of rectifier at positive \oplus side
 - a. While using an ohmmeter, connect one tester probe to the positive stud. Also, connect the other probe to each of the rectifier terminals.




WRU90-CH039

- b. Repeat the same steps described in a. above with the polarity of the tester probes reversed this time.
 - c. Ensure that continuity exists either in the step a. or in the step b. and no continuity exists at the other test.
- If not, replace the rectifier holder.




WRU90-CH040

- ② Inspection of rectifier at negative \ominus side
 - a. While using an ohmmeter, connect one tester probe to each rectifier negative terminal. Also, connect the other probe to each rectifier terminal.



WRU90-CH041


- b. Repeat the same steps described in a. above with the polarity of the tester probes reversed this time.
 - c. Ensure that continuity exists either in the step a. or in the step b. and no continuity exists at the other test.
- If not, replace the rectifier holder.



WRU90-CH042


(5) Bearings

- ① Inspection of front bearing
Ensure that the bearing turns smoothly.
Replace the bearing, if necessary.




WRU90-CH043

- ② Replacement of front bearing (If necessary)
 - a. Remove the four screws and retainer plate.




WRU90-CH044

- b. Remove the front bearing from the drive end frame, using a socket wrench in conjunction with a press.




WRU90-CH045

- c. Press the new front bearing into the drive end frame, using suitable socket wrench.




WRU90-CH046

- d. Attach the retainer plate to the drive end frame with the four screws.



WRU90-CH047

- ③ Inspection of rear bearing
Ensure that the bearing turns smoothly.
Replace the bearing, if necessary.




WRU90-CH048

- ④ Replacement of rear bearing (if necessary)
a. Remove the rear bearing and bearing cover from the rotor, using the armature bearing puller.


NOTE:

- Be very careful not to damage the fan during the removal.



WRU90-CH049


- b. Press a new rear bearing with spacer, using a hydraulic press.
c. Press a new bearing cover, using a suitable steel pipe.



WRU90-CH050

9. ASSEMBLY

(1) Install the rotor into the drive end frame assembly.




WRU90-CH051

(2) Installation of rectifier end frame on drive end frame.
Install the rectifier end frame on the drive end frame with the two bolts and two nuts.

NOTE:


- Be very careful not to damage the stator wire during the installation.
- If some resistance is encountered during the insertion, lightly tap the frame with a plastic hammer.



WRU90-CH052


(3) Installation of rectifier holder, regulator assembly and brush holder.

① Attach the rectifier holder to the end frame with the coil wires passed through the aperture of the rectifier holder.




WRU90-CH053

② Wind the coil wire around the installing section of the rectifier attaching screws.




WRU90-CH054

③ Secure the four attaching screws.




WRU90-CH055

- (4) Install the regulator assembly with the three attaching screws.



WRU90-CH056


- (5) Install the brush holder in such a way that a gap of at least 1 mm (0.04 inch) is provided between the brush holder and the regulator assembly. Secure the brush holder with the two screws.



WRU90-CH057

- (6) Installation of rear cover

- ① Install the rear end cover with the three attaching screws.
- ② Install the terminal insulator and tighten it with the nut.




WRU90-CH058

- (7) Attach the pulley to the alternator shaft.
 (8) Tighten the SST B to the specified torque. Secure the the SST B to the alternator shaft.

SSTs: 09820-87201-000

Specified Torque: 39 N·m (4 kgf-m)




WRU90-CH059

- (9) Clamp the SST C in a vise. Tighten the nut by turning the SST B.

Specified Torque: 110 N·m (11.25 kgf-m)


- (10) Remove the SSTs A and B.



WRU90-CH060

CHARGING SYSTEM


(11) Ensure that the rotor turns smoothly.



WRU90-CH061


10. INSTALLATION

- (1) Temporarily install the alternator on the engine with the two attaching bolts.
- (2) Connection of wire to alternator
 - ① Connect the connectors to the alternator.



WRU90-CH062

- ② Install the wire and nut to the alternator.




WRU90-CH063

- (3) Installation of alternator drive belt

- ① Install the alternator drive belt properly.

NOTE:

- Make sure that the alternator drive belt is properly engaged in the grooves of each pulley.



WRU90-CH064

- ② Tension adjustment of drive belt

Adjust the belt tension in such a way that the deflection of the drive belt meets the specification when you push the midpoint of the drive belt between the alternator pulley and the water pump pulley by applying a force of 10 kg (22 lb).


Specified Belt Deflection

New belt: 4.0 - 5.0 mm (0.16 - 0.20 inch)

Used belt: 5.0 - 6.0 mm (0.20 - 0.24 inch)

NOTE:

- "New belt" refers to a belt with has been used less than 5 minutes on a running engine.
- "Used belt" refers to a belt which has been used on a running engine 5 minutes or more.
- If belt replaced with new one, run the engine for about 5 minutes and then recheck the tension.



WRU90-CH065

CHARGING SYSTEM

(4) Reconnect the ground cable terminal to the negative (–) terminal of the battery.

WRU90-CH066